



TEL: 0114 24 34 200 **SPARE PARTS**




STEP 1

Lay out all Posts & components



STEP 2

Insert small quick release black button into Insert Blanking Cap Insert small quick release black button Spigots and insert one Large Quick Release Button into each T Bracket, this is to lock the upright posts.




STEP 3

and insert Large Quick Release **Bracket**

CORNER

uprights


BRACKET for



stanchion connector

CORNER


BRACKET



STEP 5 Insert Arrow Head Net Fixings into Upright Posts and into crossbar.




Insert Ground Frame net Fixings into Back bar and Side bar. see details about removing burrs overleaf.







Insert Corner Brackets X into the upright posts **\$** (uprights have logos on the side)




STEP 9

Insert Corner Brackets A into each end of the Backbars 0





STEP 11 Attach Side bars R to the ground back frame, connect both back Attach Upright S to bars together with the the Side bars R straight connector M




STEP 12


Fit crossbar onto uprights.



Join top tubes T to elbows G and back tubes **U** and connect to the goalpost.



SECURE GOALS TO SEPARATE ANCHOR POINTS.



STEP 8

Insert T Brackets into

tighten nuts bolts

each end of the crossbar.

STEP 14

Attach Top Tubes using nuts and bolts. Fit Ground Anchors over the ground base see details of use overleaf.



Attach The Net to the Net Fixings. Start with each corner

TIE A CORD BETWEEN THE TOP SUPPORT TUBES TO SUPPORT THE ROOF OF THE NET (THIS CAN BE LEFT TIED IN POSITION WHEN DISMANTLED)





The goal net can be left attached to the pre-assembled goal post side frames. After games detach crossbar and back bar for storage. We advise fitting the

optional net ties to the side frames and stanchions.


OPTIONAL - Net ties are ideal to fit nets tightly to the side ground frames and stanchions. This is ideally when nets are left attached to the fully assembled side frames.















DO NOT THROW THE PINS AWAY



Insert Arrow Head into Holes on posts



Push locking pin Down centre of Arrow Head

Ensure locking

pin is inserted

fully



Ensure locking pin Is inserted Fully in the posts

At the end of the season nets can be tied into a bundle and placed into a pillow case (not to damage washing machine) and washed at 40 C0 with normal washing powder. The ground frame can be washed with hot soapy water. Any scuff marks on posts can be rubbed off with a light abrasive

WARNING: Check the position of any underground services before using the ground anchors and pegs. We take no responsibility for any damage or injury caused in this manner

NEVER use the goals without the ground anchor system. In severe weather or windy conditions it is advisable to take your goal down as gamage is not covered by the guarantee in such circumstances. If you find the nets are worn along the floor it may be rodents, by spreading pepper along the base frame rodents will be deterred.

It is advisable in any contact sport to take out the relevant insurance's to cover against injury both from taking part, equipment and other unforeseeable circumstances.

Crossbars will not be replaced within the guarantee period if broken by swinging or climbing or any other

DO NOT try to glue any damaged fixings. Plastic materials in this product vary and this may cause the plastic to break. Always replace any damaged components.





Insert ground frame net fixings into holes on ground frame



Push locking pin down centre

On back frame fix all the same way with opening facing


inwards. On side frames along the ground fit alternate




inserted fully, nip the plastic lugs off so the fixing sits flush



Push the rod slightly inside. Make sure the rod does not go fully through and fall out or the fixing will not lock







SQUARE MESH Net is cut to shape. Simply throw over the frame and fit each end onto top stanchion by securing on each corner of crossbar.


NOTE: If your net does not fit the first time, you may be fitting it to the goal frame upside down i.e. that is to say the net from the crossbar to the floor (a) is longer than the length of the net to the bottom of the upright (b) We advise adult supervision during assembly and use. Observe and follow warning labels attached to goal. Do not use any components, nets or parts if they are damaged or broken. Spare parts and replacement nets are readily available. If others are to install your goal you should show them how to erect and dismantle the goal and hand them a copy of the fitting instruction. If you lose your instructions copies can be attained from our company website. To avoid damage when dismantling the goal follow these guidelines: it is advisable in extreme windy conditions to dismantle the goal and store away. Do not drop any heavy objects on ends of tubes. When dismantling the goal ensure that all fittings are packed away and that non are left on the playing surface. Warning goals must never be left up or used unless they are properly fitted with ground anchors with net attached and securely pegged down.

Hard surfaces: to prevent damage to goal or it's components, loosen soil with a steel pole and moisten with some water before inserting the ground anchors. Do not use the goal in sub zero temperatures. warning labels should be replaced when worn and we recommend replacing them every two years -spare labels available, damaged components requested under guarantee must be returned for inspection. Failure to follow the warnings, fitting instructions contained in this document, may invalidate your quarantee. The company, its agents and representatives do not accept any product liability if used outside the EU. Use of the product in other countries outside the EU including the USA is not covered and appropriate insurance should be taken out by the user to cover for any eventuality. We reserve the rights to amend the specifications of our soccer products in the interest of continued development. Your product therefore may differ slightly to those illustrated. Not suitable for children under 36 months until assembled due to small parts.

NOTE: All plastic extrusions vary and therefore some tubes may be looser or tighter to connector fittings. If you want to increase the diameter of the fitting just wrap masking tape around the part that fits into the tube, twist as you insert the fitting and it will grab to the tube tight ... you can make tighter fits by adding more tape.










To register for your guarantee please visit our web page


www.itsagoal.net
and scroll to the bottom of the page and click on the link 'Guarantee' and follow the instructions. Thank you

NET TIES (A)


Ensure the teeth of the Net tie are facing you (see step 1). Loop the Net Tie around the Net Cord and slide the end into the horizontal slot and pull tight onto Net Cord (see step 1-2)



The vertical slot of the Net Tie is used to secure the net to the post. Loop the Net Tie around the post and insert through vertical slot and twist to lock. (steps 3 - 5).



Any excess Net Tie can looped back into the vertical slot. This will also secure the net tie in a fixed position (steps 6 - 8). If Net Ties are to be removed after use then do not loop back into vertical slot





SPARE PARTS

TEL: 0114 24 34 200