


STEP 5




Lay out all Posts & components



STEP 2

Spigot and insert into T bracket. Insert Large Quick Release Buttons into the T Brackets.



STEP 3

and insert Large Quick Release Bracket X

CORNER


uprights

BRACKET for



stanchion connector


CORNER



Insert Arrow Head Net Fixings into Upright Posts and into crossbar.




Insert Ground Frame net Fixings into Back bar and Side bar. see details about removing burrs overleaf.






Insert Corner Brackets X into the upright posts **\$** (uprights have logos on the side)



STEP 8

Insert T Brackets into each end of the crossbar. tighten nuts bolts




STEP 9

Insert Corner Brackets A into each end of the Backbars



back frame, connect both back bars together with the straight connector SC





STEP 12

Fit the crossbar together then fit crossbar onto uprights.



Join top tubes P to elbows G and back tubes Q and connect to the goalpost.





STEP 14

Attach Top Tubes using nuts and bolts. Fit Ground Anchors over the ground base see details of use overleaf.

STEP 15


Attach The Net to the Net Fixings. Start with each corner


TIE A CORD BETWEEN THE TOP SUPPORT TUBES TO SUPPORT THE ROOF OF THE NET (THIS CAN BE LEFT TIED IN POSITION WHEN DISMANTLED)





be left attached to the < pre-assembled goal post side frames. After games detach crossbar and back bar for storage. We advise fitting the


optional net ties to the side frames and stanchions.











ANCHORING YOUR GOAL ON GRASS - POSITION YOUR GOAL ON A LEVEL PLAYING SURFACE. PLACE THE MULTI-SURFACE ANCHOR OVER EACH SIDE OF THE GROUND FRAME (POSITIONS SHOWN) HAMMER THE PEGS DOWN UNDER THE FRAME INTO THE GRASS. ADDITIONAL ANCHORS OR LARGER PEGS CAN BE PURCHASED FOR USE ON SOFT GROUND OR SAND. ANCHORS CAN BE USED FOR HARD SURFACES. SUCH AS TARMAC BY USING BOLTS THROUGH THE MULTI SURFACE ANCHORS INTO CONCRETE PADS. COUNTER BALANCE WEIGHTS CAN ALSO BE USED (SUPPLIED SEPARATELY). CHAINS ARE AVAILABLE SEPARATELY THAT CAN BE USED TO SECURE GOALS TO SEPARATE ANCHOR POINTS



DO NOT THROW THE PINS AWAY



GROUND FRAME


Insert ground frame

net fixings into holes

on ground frame

NET FIXING

Insert Arrow Head into Holes on posts



Push locking pin Down centre of Arrow Head

Ensure locking

pin is inserted

fully

Push locking

pin down

On back frame fix all the same way with opening facing

inwards. On side frames along the ground fit alternate

centre



Ensure locking pin Is inserted Fully in the posts

At the end of the season nets can be tied into a bundle and placed into a pillow case (not to damage washing machine) and washed at 40 C0 with normal washing powder. The ground frame can be washed with hot soapy water. Any scuff marks on posts can be rubbed off with a light abrasive

WARNING: Check the position of any underground services before using the ground anchors and pegs. We take no responsibility for any damage or injury caused in this manner

NEVER use the goals without the ground anchor system. In severe weather or windy conditions it is advisable to take your goal down as gamage is not covered by the guarantee in such circumstances. If you find the nets are worn along the floor it may be rodents, by spreading pepper along the base frame rodents will be deterred.

It is advisable in any contact sport to take out the relevant insurance's to cover against injury both from taking part, equipment and other unforeseeable circumstances.

Crossbars will not be replaced within the guarantee period if broken by swinging or climbing or any other

DO NOT try to glue any damaged fixings. Plastic materials in this product vary and this may cause the plastic to break. Always replace any damaged components.




lugs off so the fixing sits flush



Push the rod slightly inside. Make sure the rod does not go fully through and fall out or the fixing will not lock

CORNER

BRACKET for



SQUARE MESH Net is cut to shape. Simply throw over the frame and fit each end onto top stanchion by securing on each corner of crossbar.


NOTE: If your net does not fit the first time, you may be fitting it to the goal frame upside down i.e. that is to say the net from the crossbar to the floor (a) is longer than the length of the net to the bottom of the upright (b)



We advise adult supervision during assembly and use. Observe and follow warning labels attached to goal. Do not use any components, nets or parts if they are damaged or broken. Spare parts and replacement nets are readily available. If others are to install your goal you should show them how to erect and dismantle the goal and hand them a copy of the fitting instruction. If you lose your instructions copies can be attained from our company website. To avoid damage when dismantling the goal follow these guidelines: it is advisable in extreme windy conditions to dismantle the goal and store away. Do not drop any heavy objects on ends of tubes. When dismantling the goal ensure that all fittings are packed away and that non are left on the playing surface. Warning goals must never be left up or used unless they are properly fitted with ground anchors with net attached and securely pegged down.


Hard surfaces: to prevent damage to goal or it's components, loosen soil with a steel pole and moisten with some water before inserting the ground anchors. Do not use the goal in sub zero temperatures. warning labels should be replaced when worn and we recommend replacing them every two years -spare labels available, damaged components requested under guarantee must be returned for inspection. Failure to follow the warnings, fitting instructions contained in this document, may invalidate your quarantee. The company, its agents and representatives do not accept any product liability if used outside the EU. Use of the product in other countries outside the EU including the USA is not covered and appropriate insurance should be taken out by the user to cover for any eventuality. We reserve the rights to amend the specifications of our soccer products in the interest of continued development. Your product therefore may differ slightly to those illustrated. Not suitable for children under 36 months until assembled due to small parts.

NOTE: All plastic extrusions vary and therefore some tubes may be looser or tighter to connector fittings. If you want to increase the diameter of the fitting just wrap masking tape around the part that fits into the tube, twist as you insert the fitting and it will grab to the tube tight ... you can make tighter fits by adding more tape.





Ensure the teeth of the Net tie are facing you (see step 1). Loop the Net Tie around the Net Cord and slide the end into the horizontal slot and pull tight onto Net Cord (see step 1-2)



Push and Lock the Small Quick

Release Buttons


into the ends of

Push and Lock the spigots into the


Brackets.

the Spigots.

The vertical slot of the Net Tie is used to secure the net to the post. Loop the Net Tie around the post and insert through vertical slot and twist to lock. (steps 3 - 5).



Any excess Net Tie can looped back into the vertical slot. This will also secure the net tie in a fixed position (steps 6 - 8). If Net Ties are to be removed after use then do not loop back into vertical slot



tsaGoal www.itsagoal.net

SPARE PARTS

TEL: 0114 24 34 200