

1. Attach your own rope into pre drilled holes. We recommend 2.6m between posts as seen on traditional pitch barriers.