


×8

×1



NET TIES

GOAL NET

NET

M SMALL STANCHION NET TIES

HEX KEY FOR COMPONENT J

GOAL POSTS MUST BE ANCHORED AT ALL TIMES


Optional longer pegs are available for use on sandy ground. On grass, a risk assessment of soil and weather conditions suitability should be carried out when anchors or optional counter weights are to be used. Please note optional guy ropes are available; the guy ropes can be fixed to both sides of the goals to provide extra stability and reduce sideways sway. TEL: 0114 2434200



CARE & MAINTENANCE - see separate sheet supplied or visit www.itsagoal.net for additional copies. Our goalpost if used correctly will last many years. We do also offer a full spare part service and if your goals need refurbishment this can be arranged.







Visit our YouTube site for assembly videos: www.voutube.com/user/Footballgoalposts

VISIT THE WEB SITE WWW.ITSAGOAL.NET TO REGISTER UK GOALPOST WARRANTY WORLDWIDE © COPYRIGHT 2016 ITSA GOAL POSTS LTD. ALL RIGHTS RESERVED A REGISTERED DESIGN

CORNER BRACKETS

BEFORE YOU START TO ASSEMBLE YOUR GOAL PREPARE THESE FIRST.

> Push and Lock the Spigots to four of the six Corner Brackets.

CORNER BRACKET. **STANCHION & ELBOW ASSEMBLY**


NOTE: Ensure Top Stanchion holes are aligned with the Stanchion Elbow.



Note: small flange bushes are already inserted to create tight fitting bolts

stanchion elbow is designed to be tight fitting, push in and out to warm up and make pliable. This makes it easier to insert and lock to part Q. Once connected this part stays in place. permanently. F **PLASTIC**


NOTE - The Plastic button on the




Insert ground frame

net fixings into holes


on ground frame



Push locking Ensure locking pin is inserted



BACKBAR FACE FORWARD



SIEBARS ALTERNATE


DO NOT THROW THE LOCKING PINS AWAY ARROW HEAD NET FIXING



Insert Arrow Head into holes on posts

NET


CHORD



J

P

Push locking pin down centre of Arrow Head






detaching the net then apply col-

to help identify the roof area.

ored tape to the roof corners of net





FASTER MATCH DAY

attached to the pre-assembled goal post side frames. After games detach crossbar and back bar for storage. We advise fitting the optional net ties to the side frames and stanchions.

ASSEMBLY & DISASSEMBLY

(Diagram A) The goal net can be left

DO NOT THROW THE LOCKING PINS AWAY

, pin down


GROUND FRAME NET FIXING

REMOVABLE NET TIES - OPTIONAL


ENSURE THAT YOU TIGHTEN THE NET TIE AROUND THE NET-CORD (no more than 340mm apart)

Ensure the teeth of the Net tie are facing you (see step 1).


Loop the Net Tie around the Net Cord and slide the end into the horizontal slot and pull tight onto Net Cord (see step 1-2).



The vertical slot of the Net Tie is used to secure the net to the post. Loop the Net Tie around the post and insert through vertical slot and twist to lock. (steps 3 - 5).




Any excess Net Tie can looped back into the vertical slot. This will also secure the net tie in a fixed position (steps 6 - 8). If Net Ties are to be removed after use then do not loop back into vertical slot.




SMALLER STANCHION NET TIES

Smaller net ties are ideal to attach nets to the side frames and the back net support tubes. These are useful when you leave your nets attached to the goals at all times as shown on the diagram to the left. (Diagram A).


ANCHORING YOUR GOAL ON GRASS - POSITION YOUR GOAL ON A LEVEL PLAYING SURFACE. PLACE THE MULTI-SURFACE ANCHOR OVER EACH SIDE OF THE GROUND FRAME (POSITIONS SHOWN) HAMMER THE PEGS THROUGH THE HOLES ON THE ANCHOR DOWN UNDER THE FRAME INTO THE GRASS. ADDITIONAL ANCHORS OR LARGER PEGS CAN BE PURCHASED FOR USE ON SOFT GROUND OR SAND. ANCHORS WITH EXTRA BOLTS CAN BE USED FOR HARD SURFACES SUCH AS TARMAC. COUNTER BALANCE WEIGHTS CAN ALSO BE USED (SUPPLIED SEPARATELY).








On back frame fix all the ground frame net fixings the same way with opening facing inwards. On side frames along the ground fit them alternate.






■ SQUARE MESH. Net is cut to shape. Simply throw over the frame and fit

OPTIONAL - NET TIES

П


each end onto top stanchion by securing on each corner of crossbar. NOTE: If your net does not fit the first time, you may be fitting it to the goal frame upside down i.e. that is to say the net from the crossbar to the floor (a) is longer than the length of the net to the bottom of the upright.(b)







anchors are to be used.



SPARE PARTS TEL: 0114 24 34 200

WORLDWIDE © COPYRIGHT 2016 ITSA GOAL POSTS LTD. ALL RIGHTS RESERVED A REGISTERED DESIGN