

COMPONENTS

A	NET TIE	x28	
B	SMALL QUICK RELEASE BUTTON	x4	
C	STRAIGHT CONNECTOR	x1	
D	STANCHION CONNECTOR	x2	
E	ARROW HEAD NET FIXING with attached LOCKING PIN	x16	
NET	GOAL NET 16' x 7'	x1	

POST SECTIONS

F1	CROSSBAR SECTION with insert 2440mm LONG plus insert - 68mm OD	x1	
F	CROSSBAR SECTION without insert 2440mm LONG - 68mm OD	x1	
G	BACKBAR SECTION 1205mm LONG - 68mm Diameter	x1	
H	UPRIGHT SECTION 305mm LONG - 68mm Diameter	x2	
I	SIDEBAR SECTION 366mm LONG - 68mm Diameter	x2	
J	TOP STANCHION TUBE 630mm LONG - 40mm Diameter	x2	
K	UPPER BACK STANCHION TUBE 336mm LONG - 40mm Diameter	x2	


DO NOT THROW THE LOCKING PINS AWAY




NET TIES

! ENSURE THAT YOU TIGHTEN THE NET TIE AROUND THE NET-CORD (no more than 340mm apart).


Ensure the teeth of the Net Tie are facing you (see step 1). Loop the Net Tie around the Net Cord and slide the end into the horizontal slot and pull tight onto Net Cord (see step 1-2).



The vertical slot of the Net Tie is used to secure the net to the post. Loop the Net Tie around the post and insert through vertical slot and twist to lock. (steps 3 - 5).




Any excess Net Tie can loop back into the vertical slot. This will also secure the net tie in a fixed position (steps 6 - 8). If Net Ties are to be removed after use then do not loop back into vertical slot.



DO NOT THROW THE LOCKING PINS AWAY

Insert ground frame net fixings in the sidebar sections and backbar sections.



12' X 6' EXTENSION KIT (12' x 6' MS to 16' x 7' MS with new 2 SECTION CROSSBAR)

