# **GOAL POST TRANSPORTER**

## Freestanding Elliptical Aluminium Goalposts

### How to use the Goal Post Transporters

The only steerable system - Exclusive to ITSA Goal

To add the Goal Post Transporters to the goals it is recommended to first lay the goal posts flat down on the ground as shown below. Hold the ground side frame vertical and slide the wheel transporter inside the bottom of the upright. Once both wheel transporters are connected carefully lift the goals up so the uprights are vertical. It is important to be very careful that the crossbar does not come away from the side frames when the goals are being moved. Always assemble on flat level ground. Make sure children are not in the vicinity when moving and anchoring goalposts.

The side frames can rotate whilst the crossbar is not locked. This allows the goals to be moved in all directions, ideal when you have to store goals in awkward storage areas. However extra care must be taken whilst the crossbar is not locked to the side frames to prevent the crossbar coming apart from the side frames and falling. We recommend When the goal posts are in position for play the barrel locks must be inserted to lock the goals as shown on the goalpost fitting instructions. Likewise when the goals are in storage the goals should have the locks in place for extra stability and to prevent the side frames swinging inward

It is also advised when the goals are in storage to make sure the goals are stored to prevent toppling and secured against a wall and not left freestanding. Always take great care with heavy freestanding football goals.

#### Set includes


Two aluminium weather proof 'T' frames, Four Puncture proof Pneumatic Wheels Set of two are required to move one goal. The wheels can be used on any number of 120mmx100mm elliptical aluminium goal posts



www.itsagoal.net


#### 735mm Width

Ideal for larger Adult & Youth size goals




#### 470mm Width

Ideal for smaller mini soccer goals.



## Insert Wheels on 3 Lift goals upright - two adults Lay goal flat both uprights down on ground. 5 Add ground back bar as 6 Insert sufficient anchors, 4 Steer/move goal into position per fitting instructions counter weights or with lock in place at the rear. chain to fixing points



### $oldsymbol{\Delta}$ WARNING

**NEVER** stand or apply any weight on the side frame marked 'A' as this can damage your equipment.



unattended with the wheel transporters still attached as shown to the left . Always move the goals into the position required and then anchor the goals to the playing surface using ground anchors or weights as recommended on the fitting instructions supplied with your goalposts. Never move the goals in extreme weather and gales. **DO NOT** remove anchors using goal frame, use the

STEERING GOALPOSTS **NEVER** leave the goals Insert lock here back of the ground peg.